



DNW-75 Series Quick Info

Subject / Question	Answer	Further Information
What is the latest available software version for this model?	SY1 V2.17, SY2 V2.14, SV V2.18	Contact BSC for upgrade details
How can I find the version of my currently installed software?	MAINTENANCE MENU->M3 (OTHERS) ->M30 (ROM VERSION)	Maintenance Manual Vol 1, Section 4-1 & 4-4-2
How to access the Maintenance Menu	On the SS-83 board press S1101 or set S1100-2 to ON then access the menu by pressing MENU->CTL/TC/UB+SET.	Maintenance Manual Vol 1, Section 4-1
How to access the Extended Menu (MENU ITEM 101 and higher)	On the SS-83 board set S1100-1 to ON then press MENU	Maintenance Manual Vol 1, Section 4-5-2
How to enable the superimposed characters on the video monitor	Connect a monitor to VIDEO OUTPUT COMPOSITE 3 (SUPER) connector and set the CHARACTER switch on the sub control panel to ON.	Operation Manual Section 3-4 Maintenance Manual Vol 1 Section 4-1
How to access / clear the Error Logger	MAINTENANCE MENU->M2 (ERROR LOGGER) or press ENTRY+MENU	Maintenance Manual Vol 1 Section 4-3
How to find which options have been installed	MAINTENANCE MENU->M3 (OTHERS) ->M30 (ROM VERSION)	Maintenance Manual Vol 1 Section 4-1 & 4-4-2
Where can I find the list of error messages?	Maintenance Manual, Vol 1, Section 3	
How to change the RECORD INHIBIT status	Tab on cassette, REC INHIBIT switch on Subsidiary Control Panel and SETUP MENU ITEM 310	Operation Manual Section 2-1-3, 3-5-3 & 7-3
How to set the REFERENCE signal	OUTREF switch on Subsidiary Control Panel and MENU ITEM 309	Operation Manual Section 3-2, 7-3 & 8-4
How to retrieve a jammed cassette	This is a task for an engineer	Maintenance Manual Vol 1 Section 2-12
How do I set the Audio Headroom?	From MAINTENANCE MENU M3 OTHERS->M37 METER HEADROOM Also set the switches on the APR-52	Maintenance Manual Vol 1 Section 4-4-7 Section 1-10-1
How to change the calendar & clock	Time setting is accessed from the ERROR LOGGER	Maintenance Manual Vol 1 Section 4-3-3
How to clean the heads	The BCT-HD12CL cleaning tape is recommended for this task (available from BSC)	Wet cleaning with ethyl alcohol can be performed by a competent VTR engineer
How to change systems (525/625)	MENU ITEM 013	Operation Manual Section 7-2

Updated: 4 Jan 2010